



$$\text{TAILING FACTOR} = \frac{BC}{AB}$$

Example calculation: Peak Height = DE = 100 mm
 10% Peak Height = BD = 10 mm
 Peak Width at 10% Peak Height = AC = 23 mm
 AB = 11 mm
 BC = 12 mm

$$\text{Therefore: Tailing Factor} = \frac{12}{11} = 1.1$$

Figure 13. Tailing factor calculation.