

$$\frac{\text{Grams of residue}}{\text{Grams of sample}} \times \frac{100 \text{ milliliters}}{\text{volume of aliquot in milliliters}} \times 100 = \text{Percent soluble in xylene}$$