



NOTE: Position Straighteners So That Cell Sides Are Located Approximately 45° From Traverse Diameters.

Figure 5D-1. Example of Flow Straightening Vanes.