


FIGURE 9 – HINGE STATIC TEST LOAD DIRECTIONS FOR BACK DOORS

BACK DOOR HINGE STATIC TEST LOAD DIRECTIONS



**NOTE: LOAD TEST THREE
ONLY FOR BACK DOORS THAT
OPEN UPWARDS**