













**Figure 407.4.7.1.3 – Elevator Control Button Identification**

Control Button	Tactile Symbol	Braille Message
Emergency Stop		 "ST"OP Three cells
Alarm		 AL"AR"M Four cells
Door Open		 OP"EN" Three cells
Door Close		 CLOSE Five cells
Entry Deck		 MA "IN" Three cells
Phone		 PH"ONE" Four cells