

Figure 14-4. Check of Anemometer Starting Torque.