Note 1: An “A” in the table indicates that the system, task, or procedure, although not required to be present, may be examined if the appropriate airplane system is simulated in the FTD and is working properly.

Note 2: Items not installed or not functional on the FTD and not appearing on the SOQ Configuration List, are not required to be listed as exceptions on the SOQ.

Note 3: A “T” in the table indicates that the task may only be qualified for introductory initial or recurrent qualification training. These tasks may not be qualified for proficiency testing or checking credits in an FAA approved flight training program.