								should be displayed simultaneously.
4.e.2	System capacity – Twilight/night mode.	Not less than: 10,000 visible textured surfaces, 15,000 light points, 16 moving models.	Not applicable				**X**	Demonstrated through use of a visual scene rendered with the same image generator modes used to produce scenes for training. The required surfaces, light points, and moving models should be displayed simultaneously.
5. Sound System. The sponsor will not be required to repeat the operational sound tests (i.e., tests 5.a.1. through 5.a.8. (or 5.b.1. through 5.b.9.) and 5.c., as appropriate) during continuing qualification evaluations if frequency response and background noise test results are within tolerance when compared to the initial qualification evaluation results, and the sponsor shows that no software changes have occurred that will affect the FTD's sound system. If the frequency response test method is chosen and fails, the sponsor may elect to fix the frequency response problem and repeat the test or the sponsor may elect to repeat the operational sound tests. If the operational sound tests are repeated during continuing qualification evaluations, the results may be compared against initial qualification evaluation results. All tests in this section must be presented using an unweighted 1/3-octave band format from band 17 to 42 (50 Hz to 16 kHz). A minimum 20 second average must be taken at a common location from where the initial evaluation sound results were gathered.								
5.a.	**Turbo-jet airplanes.**							All tests in this section should be presented using an unweighted 1/3-octave band format from at least band 17 to 42 (50 Hz to 16 kHz). A measurement of minimum 20 s should be taken at the location corresponding to the approved data set. Refer to paragraph 7 of Appendix A, Attachment 2.
5.a.1.	Ready for engine start.	Initial evaluation: Subjective assessment of 1/3 octave bands. Recurrent evaluation: cannot exceed ±5 dB difference on three consecutive bands when compared to initial evaluation and the	Ground.	Normal condition prior to engine start. The APU must be on if appropriate.			**X**	