
x
x = distance from the center of the outlet to the edge of the tank, plus two inches
TOUT
TO SCALE OR WATER METER
FLOW REGULATOR
8"
TIN
EXPANSION TANK
WATER SUPPLY MAIN
CHECK VALVE

Figure 6.