Weighted average delivered efficiency: $\eta_{avg} = \Sigma\ \eta_i \times F_i$, % Eq. 19

Weighted average emissions: $E_{avg} = \Sigma E_i \times F_i$, % Eq. 20